
ZYXEL

NR7501

5G NR Outdoor Router



Package Contents



Support Information

 $\qquad \qquad \ \, \Box \ \, \text{https://service-provider.zyxel.com/global/en/tech-support}$




See the User's Guide at www.zyxel.com for more information, including customer support and safety warnings.

EU Importer


Zyxel Communications A/S Gladsaxevej 378, 2. th. 2860 Søborg, Denmark https://www.zyxel.com/dk/da/

Copyright @ 2023 Zyxel and/or its affiliates. All Rights Reserved. [$\|$


Location Examples



Step 1 SIM Card Installation




Make sure there is no Ethernet cable connected providing power using PoE. Insert your Micro/3FF SIM card provided by a 5G NR SP (Internet Service Provider) into SIM card slot. Make sure the SIM card is fully inserted into the card slot.




1-4) Follow steps 1 to 4 in the drawing to connect an 8-pin Cat 6e Ethernet cable to the Zyxel Device's LAN port.

Step 3 PoE Cable Connections




- ① Connect the other end of the Ethernet cable to the provided PoE injector's **PoE** port.
- 2 Use an Ethernet cable to connect the injector's **LAN** port to a router/gateway for initial configuration.
- 3 Connect the PoE injector to a power outlet.
- 4 Check the LEDs next to the SIM card slot.

Step 4 Initial Setup with the Zyxel Air App and WiFi




- 1 Scan the QR code on the device label then follow the prompts to connect to the WLAN on your mobile device. If you cannot connect to the Zyxel Device WiFi, check if WiFi is on. If not, press the **RESET** button for 2 seconds to reboot the Zyxel Device to enable WiFi.
- 2 You can download the Zyxel Air app or use the Web Configurator (see next) to manage the Zyxel Device.
- 3 Remove the label from the side of the Zyxel Device and put it on the injector. Scan the Login QR code to use the default user name and password to log in the Zyxel Air app for the first time.
- 4 Make sure the o-ring is in the correct position. Screw the SIM card slot cover into place according to the sequence shown. Make sure the cover is in the correct position and tightly screwed to the Zyxel Device.




Open a web browser and go to https://192.168.1.1. Enter the default user name (admin) and password (see label), and then click **Login**. Note: After configuring the Zyxel Device, turn its WiFi off.

Mounting Option 1: Pole Mounting




Insert the hose clamps into the holes on the Zyxel Device. Use a screwdriver to tighten the hose clamps and secure the Zyxel Device to the pole.

Mounting Option 2: Wall Mounting - Tilt and Turn




- 1 Use flange nuts to attach the device bracket to the back of the Zyxel Device.
- 2 Follow step 2 in the drawing to align the main bracket with the middle bracket. Place the spring washer and washer on the screw bolt and insert the screw bolt through the holes to secure it.
- 3 Follow step 3 in the drawing to align the middle bracket with the device bracket. Place the spring washer and washer on the screw bolt and insert the screw bolt through the holes to secure it.
- 4 Follow the steps in **Wall Mounting** to complete the installation.



- 1 Select the wall mounting direction (horizontal or vertical).
- 2 Use flange nuts to attach the device bracket to the back of the Zyxel Device.
- 3 Follow step 3 in the drawing to align the main bracket with the device bracket. Place the spring washer and washer on the screw bolt and insert the screw bolt through the holes to secure it.
- 4 Follow the steps in **Wall Mounting** to complete the installation.

Wall Mounting



- 1 Use the four corner holes of the main bracket to mark holes on a wall. Drill four holes in a wall.
- 2 Insert the nylon wall plugs into the holes.

3 Use tapping screws to secure the main bracket to the wall through the nylon wall plugs.

Step 5 Wall Mounting Angle Adjustment to Find the Optimal Signal for Zyxel Device

