



Quick Start Guide

US Importer: Zyxel Communications, Inc  
1130 North Miller Street Anaheim, CA 92806-2001  
<https://www.zyxel.com/us/en/>  
Copyright © 2022 Zyxel and/ or its affiliates. All Rights Reserved

Hardware Connections

- 1



Connect the fiber optic cable to the **PON** port.  
  
**Warning!** To avoid possible eye injury, do NOT look into an operating fiber-optic module's connector.
- 2





Connect a computer to the **2.5GbE** port using the yellow Ethernet cable.
- 3

Connect a phone to the **VOIP** port using a phone cable.
- 4

Connect the power adapter to the PM5311-T0 and press the **ON/OFF** button in.
- 5

Make sure the LEDs are on and check the status.



 POWER	<b>Blue</b> <b>On</b> - Power is on. <b>Blinking</b> - Starting up. <b>Off</b> - Power off. <b>Red</b> <b>Blinking</b> - Upgrading firmware.
 PON	<b>Blue</b> <b>On</b> - PON connection ready. <b>Blinking</b> - Trying to link up. <b>Off</b> - Link off.
 LAN	<b>Blue</b> <b>On</b> - 2.5G, 1000/100 Mbps link up. <b>Blinking</b> - Transmitting/receiving data. <b>Off</b> - Link down.
 PHONE	<b>Blue</b> <b>On</b> - SIP account registered. Ready. <b>Blinking</b> - Telephone off-hook or incoming call. <b>Off</b> - SIP account not registered.

# Troubleshooting

**The PM5311-T0 doesn't turn on.**

- Make sure the power cable is connected, and the power button is pushed in.
- Make sure the power adapter is connected to an appropriate power source. Make sure the power source is turned on.

**I cannot see or access the Login screen in the Web Configurator.**

- Make sure you are using the correct IP address. Set your computer's IP address to 192.168.0.100.
  - The default device IP address is 192.168.0.1. If you changed the IP address and have forgotten it, reset the PM5311-T0 to its factory defaults.
- Make sure your Internet browser does not block pop-up windows and has JavaScript enabled.
- Make sure you have entered the **Username** and **Password** correctly.

Enter the default **Username** (admin) and **Password** (on the device label), and then click **Login**. If you changed the default password, please enter the new password. If you cannot remember the new password, use a pin to push the **RESET** button for more than 5 seconds to return the device to the factory defaults, including admin password on the back label.

**I cannot access the Internet.**

- Check the hardware connections and the LED behavior. If the **PON** LED is off, restart the PM5311-T0. Check if the fiber cable has come loose or is damaged. Contact the vendor to replace any damaged cables.
- If you were given ISP account information, log into the web configurator and check that the settings are correct in the **Interface > Internet** and **Maintenance > System Restart** menus.
- Disconnect all the cables from the PM5311-T0 and reconnect them.


Note: If problems persist, please contact your vendor or customer support.

## Legal Information

Display the following legal information by going to <http://x.x.x.x/legal>. Where "x.x.x.x" is the PM5311-T0's IP address.

### Legal and Regulation

Model Name: PM5311-T0  
Product Name: GPON VoIP Bridge ONT with 2.5GbE LAN  
Importer: Zyxel Communications, Inc, 1130 North Miller Street Anaheim, CA92806-2001



IC\_Warning: CAN ICES-003(B)/NMB-003(B)

#### FCC Warning Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:


(1) This device may not cause harmful interference, and  
(2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This product has been tested and complies with the specifications for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used according to the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this device does cause harmful interference to radio or television reception, which is found by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna  
Increase the separation between the equipment or devices  
Connect the equipment to an outlet other than the receiver's  
Consult a dealer or an experienced radio/TV technician for assistance



## Safety Warnings

- DO NOT use this product near water, for example, in a wet basement or near a swimming pool.
  - DO NOT expose your device to dampness, dust or corrosive liquids.
  - DO NOT store things on the device.
  - DO NOT install, use, or service this device during a thunderstorm. There is a remote risk of electric shock from lightning.
  - Connect ONLY suitable accessories to the device.
  - DO NOT open the device or unit. Opening or removing covers can expose you to dangerous high voltage points or other risks.
  - ONLY qualified service personnel should service or disassemble this device. Please contact your vendor for further information.
  - Make sure to connect the cables to the correct ports.
  - Place connecting cables carefully so that no one will step on them or stumble over them.
  - Always disconnect all cables from this device before servicing or disassembling.
  - Please use the provided or designated connection cables/power cables/ adaptors. Connect it to the right supply voltage (for example, 110V AC in North America or 230V AC in Europe). If the power adaptor or cord is damaged, it might cause electrocution. Remove it from the device and the power source, repairing the power adapter or cord is prohibited. Contact your local vendor to order a new one.
  - DO NOT allow anything to rest on the power adaptor or cord and do NOT place the product where anyone can walk on the power adaptor or cord.
  - DO NOT use the device outside, and make sure all the connections are indoors. There is a remote risk of electric shock from lightning.
  - DO NOT obstruct the device ventilation slots, as insufficient airflow may harm your device.
    - For example, do not place the device in an enclosed space such as a box or on a very soft surface such as a bed or sofa.
  - The following warning statements apply, where the disconnect device is not incorporated in the equipment or where the plug on the power supply cord is intended to serve as the disconnect device,
    - for permanently connected devices, a readily accessible disconnect device shall be incorporated external to the equipment;
    - for pluggable devices, the socket-outlet shall be installed near the equipment and shall be easily accessible.
  - Caution! The RJ-45 jacks are not used for telephone line connection.
- APPAREIL À LASER DE CLASSE 1  
Conforme au 21 CFR 1040.10 et au 1040.11, à l'exception de la conformité au IEC60825 3e éd., comme décrit dans « Laser Notice No. 56 » du 8 mai 2019.  
Attention – L'utilisation des commandes ou réglages ou l'exécution des procédures autres que celles spécifiées dans les présents exigences peuvent être la cause d'une exposition à un rayonnement dangereux.  
CLASS 1 LASER PRODUCT & "IEC 60825-1:2014"  
Complies with 21 CFR 1040.10 and 1040.11 except for conformance with IEC 60825-1 Ed. 3., as described in Laser Notice No. 56, dated May 8, 2019.  
Caution – Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

## Wall Mounting (Optional)

6

1. Drill two holes 63 mm apart.
2. Install screw anchors and screws (not provided) in the holes.
3. Hang the PM5311-T0 on the screws.

